


HOME DECORATORS C O L L E C T I O N

BF-25159 OXFORD SHOE STORAGE WITH TWO LAYER DRAWERS 54"HX42"W

INV#16124













ASSEMBLY INSTRUCTIONS


Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.


PARTS LIST		
A  TOP PANEL-1PC	B  LEFT SIDE PANEL-1PC	C  RIGHT SIDE PANEL-1PC
D  STAND PANELS-3PCS	E  UP ACROSS PANEL-1PC	F  UP STAND PANELS-2PCS
G  DOWN STAND PANELS-2PCS	H  DOWN ACROSS PANEL-1PC	I  BOTTOM PANEL-1PC
J  ADORNING PANEL-1PC	K  SHELVES-5PCS	L  LEFT SHELVES-5PCS

M


RIGHT SHELVES-5PCS

N


REAR PANEL GUIDES-2PCS

O


DRAWER PANEL SIDES-12PCS

P


DRAWER PANEL BACKS-6PCS

Q


DRAWER PANEL BOTTOMS-6PCS

R

DRAWER PANEL FRONTS-6PCS

S


FOOT-1PC

T


LEFT BACK PANELS-2PCS

U

MIDDLE BACK PANEL-1PC

V


SHELVES-5PCS

W

CAM-BOLTS-48PCS

X


CAM-LOCKS-48PCS

Y


KNOBS-6PCS

Z

8mm × 5/8"




SCREWS-6PCS

A1


DOWELS-10PCS

B1

6mm × 3/4"




SCREWS-54PCS

C1

SHELF SUPPORTS-80PCS

D1


7mm × 5/8"



SCREWS-45PCS

E1

PLASTIC BELTS-2PCS

F1

HOOKS-4PCS

G1

GECKOS-4PCS

H1

7mm × 7/8"





SCREWS-4PCS

I1

CAM-TOOL-1PC




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: ● UPON OPENING THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: ● THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1). ASSEMBLE THE DOWN STAND PANEL (G).

- ROTATE 4 CAM-BOLTS (W) INTO THE HOLES IN THE DOWN ACROSS PANEL (H).
- PLACE CAM-BOLTS (W) INTO THE HOLES IN THE DOWN STAND PANELS (G) AND ATTACH USING 4 CAM-LOCKS (X).




2). ASSEMBLE THE UP ACROSS PANEL (E).

- ROTATE 4 CAM-BOLTS (W) INTO THE HOLES IN THE UP ACROSS PANEL (E).
- PLACE CAM-BOLTS (W) INTO THE HOLES IN THE DOWN STAND PANELS (G) AND ATTACH USING 4 CAM-LOCKS (X).




3). ASSEMBLE THE ADORNING PANEL (J).

- ROTATE 4 CAM-BOLTS (W) INTO THE HOLES IN THE ADORNING PANEL (J).
- PLACE CAM-BOLTS (W) INTO THE HOLES IN THE BOTTOM PANEL (I) AND ATTACH USING 4 CAM-LOCKS (X).




4). ASSEMBLE THE BOTTOM PANEL (I).

- ROTATE 6 CAM-BOLTS (W) INTO THE HOLES IN THE BOTTOM PANEL (I).
- PLACE CAM-BOLTS (W) INTO THE HOLES IN THE STAND PANELS (D) AND ATTACH USING 6 CAM-LOCKS (X).




5). ASSEMBLE THE DOWN ACROSS PANEL (H).

- ROTATE 6 CAM-BOLTS(W) INTO THE HOLES IN THE DOWN ACROSS PANEL (H).
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE STAND PANELS(D) AND ATTACH USING 6 CAM-LOCKS (X).




6). ASSEMBLE THE LEFT SIDE PANEL (B).

- ROTATE 6 CAM-BOLTS(W) AND INSERT 2 DOWELS(A1) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE PANEL (E/H/I) AND ATTACH USING 6 CAM-LOCKS (X).




7). ASSEMBLE THE RIGHT SIDE PANEL (C).

- ROTATE 6 CAM-BOLTS(W) AND INSERT 2 DOWELS(A1) INTO THE HOLES IN THE RIGHT SIDE PANEL (C).
- PLACE CAM-BOLTS(W) INTO THE HOLES IN THE PANEL (E/H/I) AND ATTACH USING 6 CAM-LOCKS (X).




8). ASSEMBLE THE FOOT (S).

- ROTATE THE FOOT (S) INTO THE HOLE IN THE BOTTOM PANEL (I).




9). ASSEMBLE THE UP STAND PANELS (F).

- ROTATE 4 CAM-BOLTS (W) INTO THE HOLES IN THE UP ACROSS PANEL (E).
- PLACE CAM-BOLTS (W) INTO THE HOLES IN THE UP STAND PANELS (F) AND ATTACH 4 CAM-LOCKS (X).




10). ASSEMBLE THE TOP PANEL (A).

- ROTATE 8 CAM-BOLTS (W) INTO THE HOLES IN THE TOP PANEL (A).
- PLACE CAM-BOLTS (W) INTO THE HOLES IN THE PANEL (B/C/F) AND ATTACH USING 8 CAM-LOCKS (X).




11). ASSEMBLE THE BACK PANEL(T/U).

- INSERT THE BACK PANEL(T/U) INTO THE SLOTS IN THE REAR PANEL GUIDE(V).
- ATTACH BACK PANEL(T/U) AND REAR PANEL GUIDES(N) USING 41 SCREWS(D1) AND 6 SCREWS(B1).




12). ASSEMBLE THE SHELF SUPPORTS (C1).

- INSERT 80 SHELF SUPPORTS (C1) INTO THE HOLES IN THE PANEL (B/C/D).




13). ASSEMBLE THE SHELVES (K/L/M/V).

- PLACE THE SHELVES (K/L/M/V) ONTO THE SHELF SUPPORTS (C1).



14). ASSEMBLE THE DRAWER.

- ATTACH DRAWER PANEL SIDES(O) USING 4 SCREWS(B1).
- ATTACH THE KNOB(Y) TO DRAWER PANEL FRONT(R) USING 1 SCREW(Z).
- INSERT THE DRAWER PANEL BOTTOM(Q) INTO THE SLOTS IN THE DRAWER PANEL SIDES(O).
- ATTACH DRAWER PANEL BACK(P) BETWEEN DRAWER PANEL SIDES(O) USING 4 SCREWS(B1).




15). ASSEMBLE THE DRAWERS.

- SLIDE THE DRAWERS INTO THE SLIDERS.
- INSERT 6 DOWELS(A1) INTO THE HOLES IN THE PANEL (A/E).


Warning

The anti-tip hardware must be used as part of assembly!



16). ASSEMBLE THE HOOKS (F1).

- ATTACH 2 HOOKS (F1) TO BACK PANELS (T) USING 4 SCREWS (D1).



17). ASSEMBLE THE ANTI-TIP HARDWARE.

- DRILL 4 HOLES INTO WALL, PLEASE REFER TO THE REAR TOP PANEL'S HOLES DISTANCE AND HEIGHT.
- PUT 4 GECKOS (G1) INTO THE HOLES IN THE WALL, AND ROTATE 4 SCREWS (H1) INTO THE GECKOS (G1).
- CONNECT THE TWO HOOKS (F1) WITH A PLASTIC BELT (E1).